

INSTRUCCIONES DE MONTAJE PARA LA CÚPULA

KAWASAKI ZX12R 02'-06'

Standard refª. 1121

Racing refª. 1123

Touring refª. 1122

1. Desmontar la cúpula original de la motocicleta.
2. Situar la cúpula "PUIG" sobre la motocicleta y fijarla con los dos tornillos posteriores.
3. Marcar la ubicación de los dos taladros (ver figura 1).
4. Retirar la cúpula.
5. Taladrar a diametro 10 mm los puntos marcados previamente (ver figura 2).
6. Colocar los 2 silemblocks con tuerca incorporada suministrados, en los taladros realizados previamente.
7. Montar la cúpula y fijarla con los 4 tornillos.

NUM.	DENOMINACIÓN	CANTIDAD
1	Silemblock con tuerca M5 incorporada	2
2	Arandela nylon ϕ 5,1 x ϕ 9,5 x 0,5	2
3	Tornillo Allen cabeza avellanada M5x16	2



figura 1



figura 2

INSTRUCTIONS TO ASSEMBLE THE SCREEN

KAWASAKI ZX12R 02'-06'

Standard refª. 1121

Racing refª. 1123

Touring refª. 1122

1. Take out the original screen.
2. Place the PUIG screen on the bike and fix it with the two rear screws.
3. Mark the location of the two front drills (see figure 1).
4. Remove the screen.
5. Drill with a 10mm diameter the two spots marked previously (see figure 2).
6. Place the two wellnuts supplied into the drills made on point 5.
7. Mount the screen and fix it with the four screws.

NUM.	DESCRIPTION	QUANTITY
1	Wellnut with an M5 incorporate nut	2
2	Nylon washer ϕ 5,1 x ϕ 9,5 x 0,5	2
3	M5x16 Allen screw	2