




1 262380 x1



2 303045 x2
Ø8



3 261502 x1
Ø16 Ø9 x 42



4 304228 x1
M8 x 100 Din 7380




5 400253
80 mm



6 261731 x1



7 261162 x2
Ø16 Ø9 x 40



8 304236 x2
M8 x 65 Din 7991



9 260523 x2
Ø16 Ø9 x 25



10 304032 x2
M8 x 50 Din 7991



11 303025 x4
Ø10



12 262381 x4
M8

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

