


# SHAD

## KTM 1290 SUPER ADVENTURE S/R '21 TOP MASTER KODV11ST




1 262778 x1



2 260983 x4  
Ø14 Ø9 x 29




3 303045 x2  
Ø8



4 304123 x2  
M8 x85 DIN 912



5 303025 x2  
Ø10



6 304331 x2  
M8 x75 DIN 7991

### ! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

