


SHAD

KTM ADVENTURE 1050 / 1090 '14-'17
ADVENTURE 1190 '14-'16
SUPER ADVENTURE 1290 '14-'17



KIT TOP K0DV17ST



1 262139 x1




2 260538 x2
Ø16 Ø9 x 9



3 260983 x2
Ø14 Ø9 x 29



4 303045 x2
Ø8



5 304123 x2
M8 x 85
Din 912



6 260817 x2
Ø14 Ø9 x 27



7 303025 x2
Ø10



8 304331 x2
M8 x 75
Din 7991

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

