




- Disconnect the control cables from the exhaust valve on the actuator side; by removing the original link pipe with the catalytic converter, also the valve connected to the link pipe and the cables are removed. The valve's servo motor should not be removed or disconnected.

### WARNING

- Fitting this exhaust system it is advisable to optimize the carburation by remapping the stock ECU or by adopting an additional ECU unit.

**ART. 8082**

**YAMAHA MT-10 / FZ-10 / SP**

Compatible with Original and LeoVince Factory-S exhaust,  
NOT compatible with LeoVince exhaust Art.15203-15203B-15203C-15203T-15405B-15405C-15405T

**CAT ELIMINATOR - STAINLESS STEEL**